

Materials for Space Exploration

Polymer Science and Technology Lab Materials Science Division Engineering Directorate Kennedy Space Center, Florida

> Dr. Luke Roberson luke.b.roberson@nasa.gov 1/14/2010



Materials Science Division Organizational Chart

NE-L Murray, S.– Chief Foster, A. – Deputy Balles, A. – Technical Integration Mgr

NE-L1 Failure Analysis and Materials Evaluation Branch

NE-L2 Materials Testing and Corrosion Control Branch NE-L3 Prototype Development Branch NE-L4 Materials and Processing Branch

NE-L5 Applied Physics Branch NE-L6 Chemical Analysis Branch

Chemical Analysis

Polymer Science and Technology Lab



Lab Overview

Mission

To develop and apply new technologies in polymer and material chemistry that benefit NASA's programs and mission

Team

2 NASA scientists, 1 co-op, and 4 contractors

Areas of Expertise

Polymer Nanocomposites
Next Generation Wire Materaials
Carbon Nanotube and Nanofiber Materials
Conductive Polymers
Polymer Processing
Fire and Polymers
Foam and Insulation Materials

Numerous Collaborative Efforts

NASA Centers (JSC, LaRC, MSFC, GSFC, GRC)

KSC Directorates (Shuttle, Ares, Orion, Ground support operations)

Academia (Alberta, FIT, GT, Harding, Illinois-Urbana Champagne, UCF, UF, USF)

Industry Space Act Agreements (Thermax, DeWAL, Sharklet, Crosslink, Sabic, Amalgam)


Industry Contracts (ARCnano, Epner)

National Aeronautics and Testing and Processing Equipment

John F. Kennedy Space Center

- Fire Testing
 - Cone Calorimeter
 - Oxygen Index**
 - UL94 fire test
 - NASA Std 6001 fire test
 - Radiant Panel*
 - NBS Smoke Chamber*
 - Two foot tunnel*
 - Glow wire ignition*
- Cryogenic Materials Testing
 - Cryogenic moisture uptake (CMU)**
 - Brittleness/Impact test **
 - Liquid helium cold finger test**
 - Single Pin-Socket Krytox Contamination Electrical Characterization under Cryogenic Conditions**
- Specialty Test Equipment

- Cellular Solid Analysis
 - -Pycnometer (closed/open cell)**
 - -Surface area measurement**
- Thermal Analysis
 - -Thermogravimetric analysis (TGA)
 - –Differential Scanning Calorimetry (DSC)
 - -Dynamic Mechanical Analysis (DMA)
- Physical Testing
 - -Tensile Test
 - -Compressive Test
 - -Pull/Peel Test
- Electrical Testing
 - -4-point probe
 - -Surface /Volume resistance
- Polymer Processing capabilities
 - -Extrusion
 - -Injection molder
 - -Fiber spinning equipment
 - -Melt, ball, and high intensity mixers



Chemochromic Hydrogen Sensors

John F. Kennedy Space Center

In collaboration with UCF

A patent-pending irreversible color changing H₂ gas sensor was developed at KSC in partnership with UCF and ASRC.


Changes color from a light tan to black in the presence of H_2 .

Can be manufactured into any polymer part, tape, fiber, or fabric material for unlimited potential uses.


■ Paint, Gloves, Coveralls, PPE


Operates under ambient and cryogenic temperatures.

Irreversible Sensor



Reversible Sensor






National Aeronautics and Chemochromic Hydrogen Sensors

John F. Kennedy Space Center




LPA OMBUU Deployment for STS 117, 118, 120, 122, 123











Antimicrobial Materials


In collaboration with Sharklet Technologies and UF





Orion Potable Water


5 Inconel 718 Tanks (14.3 gal) Miles of Titanium water lines

- Efficacy studies after 21 days decreases biofilm formation
- Easy to imprint during manufacture of polymer articles through a coining process
- Can be used in conjunction with antimicrobial polymers









Antimicrobial Materials

In collaboration with University of Alberta and Sharklet


Microgravity Flight Experiments


BIOLOGICAL ANALYSIS

Confirm efficacy of *Pseudomonas fluorescens* bacteria species with Sharklet[®] topography coupons and different surface treatments


– How well does it work in μG and lunar G compared to 1G?

















Wire System Materials


Insulation and Repair Materials


CNT Ink formulations




Journal of Nanoscience and Nanotechnology, 6, 2006








Substrate







CNT Ink Dust Screens

After

In collaboration with Electrostatics Laboratory








CNT Ink Printed Circuitry


In collaboration with Crosslink


Screen printed polymer-composite material

Line thickness and width increases conductivity

50 Ohm resistance able to measure damage to circuits







John F. Kennedy Space Center

Cryogenic Materials Development

In collaboration with Electrostatics Laboratory


- Foam insulation materials
 - AeroFoam (patent pending)
 - Syntactic foams








- Ice release coatings
 - Shuttle Ice Liberation Coating (SILC)
 - Dow UCAR 439 and 627
 - Luna Innovations icephobic coating



- Structural aerogel composites
 - AeroPlastic (patent pending)
 - Polyamides
 - Polyetherimides
 - Polyolefins




Fire and Polymers

John F. Kennedy Space Center

- Flame retardant strategies
 - Polymethoxyamide derivatives for high temperature engineering polymers (patent issued)
 - Carbon nanotube synergistic FR properties
 - Polyhedral Oligomeric Silsesquioxanes (POSS)
 FR properties

NMP, LiC1



- Wire insulation
- Thermal insulation
- Ablator



- Ares I
- Ares V
- Orion


$$CI \longrightarrow CI + H_2N \longrightarrow NH_2$$











The Importance of Lighting

Electric Lamp Options

	Lamp Type	Conversion* Efficiency	Lamp Life* (hrs)	Spectrum
•	Incandescent/Tungsten**	5-10%	2000	Intermd.
•	Xenon	5-10%	2000	Broad
•	Fluorescent***	20%	5,000-20,000	Broad
•	LEDs (red and blue)****	25%	100,000 ?	Narrow
•	Metal Halide	25%	20,000	Broad
•	High Pressure Sodium	30%	25,000	Intermd.
•	Low Pressure Sodium	35%	25,000	Narrow
•	Microwave Sulfur	35-40%+	?	Broad


^{*} Approximate values.


^{**} Tungsten halogen lamps have broader spectrum.

^{***} For VHO lamps; lower power lamps with electronic ballasts last up to ~20,000 hrs.

^{****} Green LEDs ~10% efficient.

Electric Lighting Systems





LED for Plant Growth


Red...photosynthesis
Blue...photomorphogenesis
Green...human vision




John Sager, KSC, Testing Prototype Flight Plant Chambers with LEDs


Carbon Nanotube Fiber Filaments


Dry Spinning of MWCNT Forests






Wet Spinning of WMCNTs







Carbon Nanotube Fiber Filaments












Spectrum of Wet CNT fiber



Summary

John F. Kennedy Space Center

